



HYTORC EDGE-.5

PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI				PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	121	17	164	104
1600	129	18	175	110
1800	145	20	197	124
2000	162	22	220	138
2200	179	25	243	152
2400	196	27	266	166
2600	212	29	287	179
2800	229	32	311	193
3000	246	34	334	207
3200	263	36	357	221
3400	280	39	380	235
3600	297	41	403	248
3800	314	43	426	262
4000	331	46	449	276
4200	348	48	472	290
4400	365	50	495	304
4600	382	53	518	317
4800	398	55	540	331
5000	415	57	563	345
5200	432	60	586	359
5400	449	62	609	373
5600	466	64	632	386
5800	483	67	655	400
6000	500	69	678	414
6200	518	72	702	428
6400	535	74	725	442
6600	552	76	749	455
6800	569	79	772	469
7000	586	81	795	483
7200	603	83	818	497
7400	620	86	841	511
7600	637	88	864	524
7800	654	90	887	538
8000	672	93	910	552
8200	689	95	934	566
8400	706	98	957	580
8600	723	100	980	593
8800	740	102	1003	607
9000	757	105	1026	621
9200	774	107	1050	635
9400	790	109	1071	649
9600	806	111	1093	662
9800	823	114	1116	676
10000	839	116	1138	690

This chart supercedes all prior version regarding this tool 03/31/2008

MAIN OFFICE 12420 TEXACO RD HOUSTON, TX 77013 713-453-6677	SOUTH TEXAS OFFICE 4802 BALDWIN BLVD CORPUS CHRISTI, TX 78408 361-888-5080	WEST TEXAS OFFICE 3508 S. COUNTY RD 1290 ODESSA, TX 79765 432-561-8481	EAST TEXAS OFFICE 2484 W. CARDINAL AVE #.4 BEAUMONT, TX 77705 409-840-9699
--	--	--	--